25X1

FROM: START
TO: H-24 (*1130*)

TIME (NLT)	RESP	ACTION	COMPLETED	
ASAP	DCOC	Complete & distrubute mission alert notification	*0730L*	
ASAP	DCOC	[ ] Acknowledge Receipt of [ ]	*0715*	25X1
ASAP	DCOC	Convert H -hour time to local and record in check list.	*0930L*	
ASAP	DCOC	Complete pilots activity schedule (5) (1-DCO, 1-M/C, 1-Flt Surg, 1-CO, 1-DCOL)	*0745L*	
ASAP	DCOC	Notify & alet the C-130 [ ]	*0730 L*	25X1 25X1
25X1		Advise that we have an airlift requirement [ ] at *511745L*. In place time here to pick up TAKE is L+2:00. *51200 L* *04/105⁰*		25X1
ASAP 25X1	DCOC	Check with DCOM to see if Msgs [ ] have been received by [ ] prior to H-24. [ ]	*-1110*	25X1 25X1 25X1
ASAP	DCOC	Check with DCOM FOR the check list to be used.	*1100*	
		(a) Custom or canned route.		ILLEGIB
		[ ]		
ASAP	TTFC	Delivers tanker schedule with all C/S - & timing.	*1415*	

Page 1

revised 16 Sept 67.

FROM: H -24:00(*1130* L)

TO: H -18:00(*1730* L)

TIME NLT	RESP	ACTION	TIME
H -~~~~			
H -23:30(*1200* L)	DCOC/	M/C attend Commander's initial briefing. Receive Ops personnel inputs for recovery team. Give to DCS. Prepare access lists for CP and Flt Following Room.	*N/R*
H -23:00(*1230* L)	SEC	Hangars secured, access lists posted.	*1230*
H -22:00(*1330* L)	COMMO	[ ] Prepare Flimsy	*0654 L*
H -21:00(*1430* L)	Flt Surg	Results of pilot physicals	*0900 L*
H -21:00(*1430* L)	DCOC	Send [ ]	*1120 L*
H -20:30(*1500* L)	COMMO	Notify DCM of Freq Channelization and translator code.	
H -19:00(*1630* L)	DCM	Complete TEB and Refuel (Item 8) #1 * (Item 3) #2	*1500* *1900*
H -19:00(*1630* L)	SEC	Advise M/C of Seat Kit No. Prm AC Kit *119* (Enter Bottom or [ ] Sec AC Kit *105*	
H -19:00(*1630* L)	DCOM	Tape Recorders ready in briefing Rm	*1500*
H -19:00(*1630* L)	COMMO	Complete Commo flimsy, cys to: M/C-3, (2 Pilots + 1 CP) and DCOMF-2	*1430*

25X1 (at H -22:00 row)

25X1 (at H -21:00 DCOC row)

25X1 (at SEC row, right side)

* DCM REGENERATION

Revised 23 August 1967

FROM: H-18:00 (_1730_ L)

TO: H-12:00 (_2330_ L)

TIME (NLT)	RESP	ACTION	TIME
H-18:00(_1730_ L)	DCOMI	Start Intelligence Briefing	_1530_
H-17:00(_1830_ L)	DCO	Supervise Plt's Initial Briefing	_1600_
H-16:00(_1930_ L)	DCM	Complete INS pre-flt (item 12) #1	_1800_
		#2	_NA_ 25X1
H-15:00(_2030_ L)	DCOM(A)	Receive [ ]	_1050 L_
H-15:00(_2030_ L)	DCM	Deliver [ ] Checkout Info.	_NR_
H-15:00(_2030_ L)	COMMO	Deliver [ ] to M/C if all Info available.	_1645_ 25X1
H-13:00(_2230_ L)	DCM	Complete [ ] (Item 13) #1	_1500_ 25X1
		#2	_1900_
H-13:00(_2230_ L)	DCOM(A)	INS Load Sheet. Deliver to INS	_2200_
H-13:00(_2230_ L)	Flt Surg	Start Crew Rest	_2200_
H-12:30(_2300_ L)	DCOM	Notify M/C of receipt of [ ] (Pkg Data) [ ]	25X1 25X1 _1110 L_
H-12:00(_2330_ L)	DCOC	Send [ ] Support Msg to [ ]	_1445 L_
H-12:00(_2330_ L)	DCOM(A)	Receive Wea update flt plan [ ]	_0145_

25X1

25X1
25X1

FROM: H-12:00 (_2330_ L)

TO: H- 2:00 (_0930_ L)'

TIME(NLT)	RESP	ACTION	TIME
H-11:30(_2400_ L)	DCOM	Package program to Pkg personnel	2250
H- 9:00(_0230_ L)	DCOW	▩ M/C item (G) <u>Wx effect</u> of ability to launch.☐	1254
25X1 H- 9:00(_0230_ L)	DCOC	Send ☐ to Hqs	1254
H- 8:30(_0300_L)	DCM	Complete Pkg Load (Item 15) #1	1730
		#2	1845

25X1

ILLEGIB

H- 4:30(_0700_ L)	DCOM(A)	Film strip complete	0555
H- 4:00(_0730_ L)	AFCS	Report Equip status to DCOC	0640
H- 3:45(_0745_L)	CMDR DCO F/Surg	Final decision on primary & spare pilot, notify DCOL	0745
H- 3:45(_0745_ L)	DCO	Current Airfield Status	0745
H- 3:30)_0800_ L)	DCM	Start INS Warm (Item 21) #1	0800
		*(Item 14) #2	0800
H- 3:30(_0800_L)	DCO	Final Briefing	0800
25X1 H- 2:30(_0700_ L)	DCOC	Send ☐ confirmation of Coord.	04/2309

* DCM REGENERATION

Revised 15 September 1967

FROM: H -2:00 (_0930_ L)

TO: L HOUR (_1130_ L)

TIME (NLT)	RESP	ACTION	TIME
H -1:30(_1000_ L)	DCOC	Notify Helicopter Section of ETD (CONTROLLER)	_0955_
H -2:00(_0930_ L)	DCOMI	E&E Packet turned in to DCOL	_1000_
H -1:35(_0955_ L)	DCOW	Letdown plates to pilots	_0840_

H -1:20(_1010_ L)	F/Surg	Pre-suiting physical	_1010_
H -1:00(_1030_ L)	DCOM	Load DCOM material both acft	#1 _1045_ #2 _1045_ _1035_
H -0:50(_1040_ L)	DCOL	Pilot to aircraft	_0946_
H -1:00(_1030_ L)	DCO	Go-No-Go decision	
H -1:00(_1030_ L)	DCOC	Activate HF (CONTROLLER)	_1000_
H -1:00(_1030_ L)	DCOC	Check latest NOTAMS	_1030_
H -1:00(_1030_ L)	DCOC	Assure Chopper alerted	_1000_
H -:45(_1045_ L)	DCOL	Pilot hooked up in acft	_1045_
H -:30(_1100_ L)	DCM	Start engine	_1058_
H -:15(_1115_ L)	DCOC	Cmdr's emerg C.L., Dash-1, CYG Ck list, [ ] in place	_1115_
H -:00(_1130_ L)	DCOC	Send [ ]	_1130_
H Hour(_1130_ L)	DCOC	Send T/O Msg to [ ]	_1130_
H +1:15(_1245_ L)	DCO	Release spare (primary)	_1245_
:30 prior to ldg	DCOC	Alert chopper (controller)	_1500_
:30 prior to ldg	DCOC	Notify Transit Alert (controller)	_1500_
:30 prior to ldg	M/C	Prepare [ ] for DTFC or DCO (clip bd) (primary)	_1430_
ASAP after ldg	DCOC	Send [ ] (Msn ldg report)	_1540_
ASAP after ldg	DCOC	Send [ ] (Mtn Msg)	_1540_

25X1 (multiple instances in right margin)

*(***

FROM: H +1:00(L)

TO: END

TIME (NLT)		RESP	ACTION		TIME
			SECONDARY LAUNCHED		
25X1 ASAP		DCOC	Send [ ]	on Primary	*NR*
ASAP		DCOC	Send [ ]	abort Msg on Prim	*NR*
H +1:00(_____L)		DCOC	Send [ ]	on Secondary	*NR*
25X1 H +1:00(_____L)		DCOC	Send [ ]	T/O on Secondary	*NR*
L -:30(_____L)		DCOC	Notify Helicopter (controller)		*NR*
L -:30(_____L)		DCOC	Notify Trans Alert (controller)		*NR*
25X1 L Hour(_____L)		DCOC	Send [ ]		*NR*
L Hour(_____L)		DCOC	Send [ ]	Canx - Give ATA	*NR*

****

ASAP after ldg	DCOC	Receive CYG Down time, then release Strip Alert/Airborne Alert Tnkr. Notify TTFC.	*1540*
ASAP after ldg	DCOC	Release Helicopter (controller)	*1540*
ASAP after Ldg	DCOC	Release C-130 [ ]	*1540* 25X1
L +:30(_____L)	AFCS	Shutdown	*1600*
25X1 L +1:30(_____L)	DCOMI	Par "C" of [ ] to DCOM	
L +3:30(_____L)	SEC	Sterilize aircraft	
L Plus (_____L)	DCOC	Release Acft to DCM	
L +4:00(_____L)	DCOM	Recording tape and film strip to Security.	
L +5:00(_____L)	DCO	Review Tanker Msn Report	
L +5:00(_____L)	DCOM	Tape of debrief to Security	
25X1 L +5:00(_____L)	COMMO	[ ]	

Next 1 Page(s) In Document Exempt